



BRUKSANVISNING USER MANUAL

SE	Bruksanvisning / Installationshandbok	2
GB	User manual / Installation manual	46

Läs bruksanvisningen noga innan du använder produkten.
Spara bruksanvisningen för framtida bruk.
Before using this product, please read the user manual
carefully. Save the user manual for future reference.



TVÄTTMASKIN / WASHER

MOD NR: CTM2714V

Innehåll

Säkerhetsanvisningar	3
Tänka på	6
<i>Flytta tvättmaskinen</i>	6
<i>Avfallshantering av produkt</i>	6
Översikt	7
Installation	8
<i>Packa upp tvättmaskinen</i>	8
<i>Avfallshandera förpackningsmaterialet</i>	8
<i>Avlägsna transportskruvar</i>	8
<i>Välja installationsplats</i>	8
<i>Injustering</i>	8
<i>Elektrisk anslutning</i>	8
<i>Vattenanslutningen</i>	9
<i>Dräneringsslang</i>	9
Använda	10
<i>Checklista och förberedelser före tvätt av kläder</i>	10
<i>Kläder som inte kan tvättas i tvättmaskin</i>	10
<i>Töm alla fickor</i>	11
<i>Dela in kläderna i följande kategorier</i>	11
<i>Använd lämpligt tvättmedel</i>	11
<i>Fyllnadsmängd</i>	12
<i>Kontrollpanel</i>	13
<i>Tabell över tvättprogram</i>	15
<i>Första användning av tvättmaskinen</i>	16
<i>Fylla på tvättmedel i tvättmaskinen</i>	16
<i>Starta tvättmaskinen</i>	16
<i>Välja tvättprogram</i>	16
Underhåll	18
<i>Rengöring och underhåll av tvättmaskinens hölje</i>	18
<i>Rengöra trumma</i>	18
<i>Frys skydd</i>	18
<i>Rengöra tvättmedelsfack och spår</i>	19
<i>Rengöra inloppsfilter</i>	19
<i>Rengöra inloppsslangens filter</i>	19
<i>Tvätta filtret i tvättmaskinen</i>	19
<i>Tömningspumpen</i>	20
Felsökning	21
Produktspecifikationer	23
Tekniska data	23

Säkerhetsanvisningar

- Om nätsladden är skadad ska denna ersättas av tillverkaren, tillverkarens servicerepresentant eller annan behörig person (skadad nätsladd kan vara mycket farlig).
- Slangsatsen som medföljer apparaten ska användas (återanvänd inte den gamla slangatsen).
- Tvättmaskinen är avsedd endast för inomhusbruk.
- Denna apparat får användas av barn från 8 år och äldre samt av personer med nedsatt fysisk förmåga, nedsatt hörsel/syn, nedsatt mental förmåga eller som saknar erfarenhet endast under överinseende av behörig person eller om de ges anvisningar om hur den används på ett säkert sätt och de förstår alla risker som föreligger. Barn får inte leka med apparaten. Rengöring och underhåll får utföras av barn endast under överinseende av vuxen person.
- Dra ut stickkontakten från vägguttaget innan du påbörjar rengöring eller underhåll.
- Försäkra dig om att alla fickor är tömda (vassa och hårda föremål som till exempel mynt, smycken, spikar, skruvar eller stenar kan skada denna maskin allvarligt).
- Kontrollera att det inte finns vatten kvar i trumman innan du öppnar luckan. Öppna inte luckan om du ser vatten inuti trumman.
- Kontrollera att djur eller barn inte har klättrat in i tvättmaskinen. Kontrollera tvättmaskinen innan varje användning.
- Luckans glasruta kan bli mycket varm under tvättning. Försäkra dig om att barn och djur inte kan komma i närheten av tvättmaskinen när tvättprogram körs.
- Försäkra dig om att nätspänningen och frekvensen överensstämmer med angivelser på tvättmaskinen märkskylt.

Säkerhetsanvisningar

- Använd inte säkringar med lägre märkström än vad som anges på tvättmaskinens märkskylt. Dra inte ut stickkontakten om du är våt om händerna.
- Nätsladden får användas endast i jordat vägguttag (annars riskerar du din egen och andra personers säkerhet). Försäkra dig om att vägguttaget är korrekt och tillförlitligt jordat.
- Förpackningsmaterial kan vara farligt för barn. Försäkra dig därför om att barn inte kommer i kontakt med något förpackningsmaterial (till exempel plastpåsar, skummaterial etc.).
- Var försiktig så att du inte bränner dig när tvättmaskinen tömmer varmt tvättvatten.
- Installera inte tvättmaskinen i fuktiga eller våta utrymmen där den kan utsättas för vattenstänk.
- Försäkra dig om att anslutning till vatten och elektricitet utförs av behörig tekniker enligt tillverkarens anvisningar och lokala säkerhetsföreskrifter.
- Avlägsna alla förpackningar och transportskruvar innan du använder tvättmaskinen. Om du inte gör det kan tvättmaskinen skadas allvarligt under användning.
- Kör ett komplett tvättprogram med tom tvättmaskin innan du tvättar den första tvätten.
- Tvättmaskinen är avsedd endast för hemmabruk och för textilier som är avsedda för maskintvätt.
- Det är inte tillåtet att tvätta mattor i maskinen.
- Fyll inte på vatten manuellt under tvättning.
- Vänta i 2 minuter efter att tvättprogrammet är avslutat innan du öppnar luckan.

- Klättra inte på maskinen och sitt inte på den.
- Luta dig inte mot luckan.
- Stäng luckan med lagom kraft (ta inte i för hårt).
Om det är svårt att stänga luckan kan det bero på att det finns kläder i vägen.
- Denna tvättmaskin är inte avsedd att byggas in.

Tänka på

Flytta tvättmaskinen


- Transportskruvarna ska monteras tillbaka på tvättmaskinen av kunnig tekniker vid ev flytt av enheten.
- Töm ur allt vatten ur tvättmaskinen innan flytt.
- Hantera tvättmaskinen med försiktighet. Håll inte i tvättmaskinens utstickande delar när du lyfter den.

Avfallshantering av produkt

Enligt lag måste elektriska och elektroniska anordningar avfallshanteras på återvinningsstation (vissa delar måste återvinnas). Elektriska och elektroniska anordningar som är märkta med en återvinningssymbol måste fraktas till återvinningsstation när de ska avfallshanteras.




Översikt




Tvättmedelsfack

(Fack 1 används EJ på denna modell)



Bipackade tillbehör



Installation

Packa upp tvättmaskinen

Packa upp tvättmaskinen och försäkra dig om att den inte har skadats under transport. Försäkra dig också om att alla komponenter enligt avsnitt "Översikt" finns medpackade. Kontakta återförsäljaren omedelbart om tvättmaskinen har skadats under transport eller om någon komponent saknas.


Avfallshandera förpackningsmaterialet

Förpackningsmaterialet till denna tvättmaskin kan vara farligt för barn. Avfallshandera det på korrekt sätt och försäkra dig om att barn inte kan komma i kontakt med det. Avfallshandera förpackningsmaterialet enligt lokala förordningar. Släng inte förpackningsmaterialet som hushållsavfall.

Avlägsna transportskruvar

Avlägsna transportskruvarna på tvättmaskinens baksida innan du använder tvättmaskinen.


1. Lossa alla transportskruvar med en blocknyckel och skruva ur dem (spara dem för framtida bruk)
2. Täck kvarvarande hål med de bipackade täcklocken.



Välja installationsplats

Innan du installerar tvättmaskinen måste du välja ut en installationsplats som har följande egenskaper:

- Stabila, torra och plana ytor (se figuren Justera ben om underlaget inte är plant).
- Försäkra dig om att ventilationen är tillräcklig.
- Rummets temperatur skall överstiga 0 °C.



Injustering

1. Lossa muttrarna på fötterna för hand.
2. Justera fötterna tills produkten står plant och balanserat.
3. Dra åt alla låsmuttrar.

Elektrisk anslutning

- Försäkra dig om att elanläggning (strömstyrka, nätspänning och ledningar) klarar av att strömförsörja apparaten, se märkskylt
- Anslut stickkontakten till ett korrekt installerat och jordat vägguttag.
- Använd inte stickkontakt eller förlängningssladd som är avsedd för olika typer av internationella kontakter.
- Ta inte i stickkontakten om du är våt om händerna.
- Håll hårt i stickkontakten när du ansluter eller kopplar ur den. Dra inte i nätsladden.
- Om nätsladden är skadad eller visar tecken på att vara trasig måste den omedelbart ersättas (kontakta tillverkaren eller servicecenter).



Installation

Vattenanslutningen

Använd med fördel auktoriserad installatör för vattenanslutning

Anslut inloppsslangen enligt anvisningar på bilden.

1. Anslut rörböjen till vattenkranen och dra åt den medurs.
2. Anslut den andra änden av inloppsslangen till inloppsventilen på baksidan av tvättmaskinen och dra åt det ordentligt (medurs).




Obs! Om det läcker från slangen efter anslutning upprepar du alla steg för anslutning av inloppsrör. Använd kran av standardtyp för vattentillförsel. Om kranen är fyrkantig eller har för stor diameter byter du till standardkran.

Dräneringsslang

Det finns två sätt att placera dräneringsslangen:


Alternativ 1: Anslut den till avloppsrör. Används när för ändamålet lämplig anslutning finns tillgänglig



Dräneringsslangen skall installeras högst 100 cm ovanför golvet.

Alternativ 2: Anslut till vattenho / öppet avlopp.

- Förankra dräneringsslangen vid installation.
- Positionera dräneringsslangen så att det inte läcker ut vatten på golvet.



Använda

Checklista och förberedelser före tvätt av kläder

Läs detta avsnitt noggrant för att undvika problem med tvättmaskinen och skada på kläder.


- Kläder som tvättas för första gången kan färga av sig. Doppa en vit handduk i tvättmedel och gnugga lätt med den på insidan eller andra dolda delar av klädesplaggen för att kontrollera om kläderna färgar av sig på handduken.
- Tvätta kläder som lätt missfärgas (till exempel sjalar) separat de första tvättningarna.
- Fläckar på manschetter, kragar eller fickor tvättas du först försiktigt med borste och flytande tvättmedel. Tvätta dem därefter i tvättmaskinen.
- Se tvättråden på kläderna innan du tvättar dem (följ anvisningar om temperatur och tvättmetod). Kläder som tvättas på fel temperatur eller med fel metod kan missfärgas eller skadas.

Kom ihåg!

Låt inte blöta kläder ligga länge i tvättmaskinen i väntan på att de ska tvättas.

Kläder som inte kan tvättas i tvättmaskin


- Vissa kläder kan tappa formen om de blötläggs i vatten:(slipsar, västar, vissa ytterplagg etc. kan krympa avsevärt om de blötläggs i vatten).
- Rynkade kläder, stärkta kläder och kläder med upphöjt tryck etc. kan tappa formen när de blötläggs i vatten.
- Vissa kläder av bomull och ylle kan lätt tappa formen
- Kläder med dekorationer och folkdräkter är exempel på produkter som lätt blir missfärgade.
- Maskintvätta inte kläder som saknar materialetikett och tvättråd.
- Tvätta inte kläder som har fläckats med kemikalier som bensin, nafta, bensen, thinner eller alkohol.



Använda


Töm alla fickor

Hårda föremål som smycken eller mynt kan skada tvättmaskinen.



Dela in kläderna i följande kategorier

- Läs tvättråden och dela in klädesplaggen enligt följande: bomull, blandfiber, silke, syntetfiber, ylle och konstfiber.
- Separera kulörta och vita klädesplagg. Nya kulörta kläder ska alltid tvättas separat första tvätten för att inte färga av sig.
- Tvättresultatet blir bättre om klädesplaggen som tvättas har olika storlek.
- Tvätta känsliga klädesplagg separat. Välj tvättprogram för ömtålig tvätt när du tvättar textilier av rent ylle, gardiner och silke. Läs tvättråden i alla plagg.
- Sortera kläderna innan du lägger in dem i tvättmaskinen. Avlägsna eventuella krokar från gardiner.
- Dekorationer på kläder kan skada tvättmaskinen. Vräng kläder som har knappar eller broderier innan du lägger in dem i tvättmaskinen.
- Dra upp alla dragkedjor och knäpp alla knappar. Knyt ihop lösa band.
- Tvätt med metalltillbehör, såsom bh, bälten och metallknappar kan skada maskinen. Lägg denna typ av tvätt i tvättpåse avsedd för ändamålet.



Använd lämpligt tvättmedel

- Använd tvättmedel avsett för tvättmaskin med trumma anpassat för de textilier som ska tvättas (bomull, syntetfiber, mjuka material och ylle).
- Anpassa mängden tvättmedel efter färg, tvättemperatur, smutsighetsgrad och typ av smuts.
- Om för mycket tvättmedel används eller om vattentemperaturen är för låg kan följden bli att allt tvättmedel inte löses upp. Resterna kan bli kvar i kläder, rör och tvättmaskinen och påverka kommande tvättar.
- Blekmedel är alkaliska och kan skada kläderna använd därför blekmedel med sparsamhet

Viktigt!

Förvara tvättmedel och andra tillsatser på en säker och torr plats oåtkomligt för barn.

Använda

Fyllnadsmängd

Om du lägger in för mycket tvätt i tvättmaskinen kan tvättresultatet försämrats. Se tabellen nedan för information om tvättmängd.


Fibertyp	Max. tvättkapacitet: 7 kg
Bomull	7,0 kg
Syntet	3,5 kg
Ylle	2,0 kg
Ömtåliga textilier	2,5 kg

Tänk på!

Kläder som luddar mycket ska tvättas separat (annars kan de ludda av sig på andra kläder). Svarta kläder och bomullskläder är exempel på kläder som lätt drar åt sig ludd och bör därmed också tvättas separat.

Använda

Kontrollpanel



1 Programratt

- Ställ in önskat tvättprogram. Se avsnitt "Välja tvättprogram" längre fram i bruksanvisningen

2 LED-display

3 AV/PÅ-knapp

- Används för att slå på och av tvättmaskinen

4 Fördröjd start / Delay

Med denna knapp ställer du in fördröjd start (0–24 timmar). Ställ in funktionen enligt följande anvisningar:

- Välj tvättprogram.
- Tryck på Delay (fördröjd start) för att välja tid.
- Tryck på START/PAUS för att aktivera fördröjd start.

Stäng av funktionen enligt följande anvisningar: Tryck på Delay (fördröjd start) tills displayen visar 0H. Funktionen kan endast stängas av innan tvättprogram har startats. Om du redan har startat tvättprogrammet avbryter du detta genom att trycka på AV/PÅ-knappen (ON/OFF).

Anmärkning: Om strömförsörjningen bryts medan tvättmaskinen kör ett tvättprogram lagras pågående tvättprogram i minnet. När strömförsörjningen är återupprättad trycker du på START/PAUS (tvättprogrammet återupptas där det stoppades).

5 Centrifugering / Speed

- Ställ in varvtalet på centrifugeringen, max 1400 varv/minut

6 Temperatur / Temp

- Ställ in temperatur, max 90°C

7 START/PAUS

- Används för att starta och pausa tvättprogram

Använda

- **Barnlås** 

Använd denna funktion för att spärra maskinen så att barn inte kan starta den.

Tryck samtidigt på "Fördröjd start" och "Centrifugering" under pågående tvättprogram (lampan tänds och "START/PAUS" samt programratten är låsta). Den enda knapp som inte är låst är "AV/PÅ".

Tryck på samma knappar samtidigt igen för att låsa upp barnlåset (symbolen slocknar).
Om strömförsörjningen till tvättmaskinen bryts slutar även barnlåset att fungera. OBS! Barnlåset är fortfarande aktivt efter tvättprogrammets slut.

- **Avaktivera ljudsignaler** 


Detta är en extra summerfunktion som tvättmaskinen är utrustad med. Håll inne "Temperatur" i 3 sekunder för att avaktivera summern (ett pip indikerar att summern är avaktiverad). För att återaktivera summern håller du inne samma knapp i 3 sekunder.

- **Lödderdämpning**

När för mycket tvättmedel används ökar mängden lödder som påverkar tvättresultatet negativt. Tvättmaskinen har en automatisk funktion som kontrollerar löddermängden och sätter igång en funktion som reducerar mängden lödder

Använda

Tabell över tvättprogram

Tvättprogram Beskrivning	Tvätt- kapa- citet	Tvättmedelsfack			Förvald tempe- ratur	Förvald tid	Förvalt centrifuge- ringsvarvtal
	(kg)	Fack I*	Fack II		°C	tim	Varv/min
Bomull Intensiv	7,0	X	●	O	40	1:58	1000
Bomull 60 °C	7,0	X	●	O	60	3:39	1400
Bomull 40 °C	7,0	X	●	O	40	3:35	1400
Bomull 20 °C	7,0	X	●	O	20	1:13	1000
Snabbtvätt 15'	2,0	X	●	O	KALL	0:15	800
Eco Tvätt	2,0	X	●	O	30	1:06	800
Sköljprogram	7,0	X	X	O	-	0:31	1000
Babykläder	7,0	X	●	O	60	1:39	1000
Sportkläder	3,5	X	●	O	40	1:19	800
Syntet	3,5	X	●	O	40	1:33	1200
Mixade material	7,0	X	●	O	40	1:13	1000
Fintvätt	2,5	X	●	O	30	1:00	600
Ylle	2,0	X	●	O	40	1:06	400
Tömning	-	X	●	X	-	0:01	0
Centrifugering	7,0	X	●	X	-	0:12	1000

*Förtvättsprogram är ej möjlig på denna modell

Energimärkning: A+++

Energitestprogram: Cotton 60 °C/40 °C (bomull), centrifugering: max. varvtal (alla andra inställningar på standardinställning).

Halv last för maskinen (7,0 kg): 3,5 kg.

Cotton 60 °C/40 °C är standardprogram för bomull (60 °C/40 °C) (se tvättråd).

Dessa tvättprogram är lämpliga för tvätt av normalsmutsig bomullstvätt. De är också det mest energieffektiva sättet (både vad gäller energi- och vattenförbrukning) att tvätta den typen av bomullstvätt.

● Krav

○ Valfritt

X Ej möjligt

Anmärkningar: Parametrarna i denna tabell är avsedda endast som referens. Faktiska parametrar kan avvika något från angivelser i ovan nämnda tabell.

Använda

Första användning av tvättmaskinen

Kör ett komplett tvättprogram med tom tvättmaskin innan du tvättar den första tvätten


1. Fyll på tvättmedel i tvättmedelsfacket och stäng det.
2. Tryck på AV/PÅ-knappen.
3. Tryck på START/PAUS-knappen.

Tvättmedelsfacket är indelat i följande fack:

I: Används EJ på denna modell.

II: Huvudtvätt

☼ Tillsatsmedel som mjukmedel eller stärkelse.



Fylla på tvättmedel i tvättmaskinen

1. Dra ut tvättmedelsluckan.
2. Fyll på tvättmedel i fack II
3. Fyll på mjukmedel i facket ☼ (om mjukmedel ska användas).

Anmärkningar:

- Vi rekommenderar att du späder ut tjocka och trögflytande tvättmedel eller tillsatser med lite vatten innan du håller dem i tvättmedelsfacket för att förhindra att det täpps igen och svämmar över när vatten fylls på.
- Välj tvättmedel som är lämpligt för de olika tvättemperaturerna (det ger bäst resultat och lägst energiförbrukning).

Starta tvättmaskinen

- Lägg i kläder och fyll på med tvättmedel och sköljmedel.
- Tryck på PÅ/AV-knappen
- Välj tvättprogram och eventuellt tillval
- START/PAUS-knappen.

Välja tvättprogram

Välj ett tvättprogram som är lämpligt för klädtypen, tvättmängden och klädernas smutsighet (se tabellen med tvättemperaturer).

1. Ställ in tvättprogram med programratten.
2. Ställ in temperatur. Generellt ökar energiförbrukningen med temperaturen.
3. Ställ in centrifugeringsvarvtal. Ju högre centrifugeringsvarvtal desto torrare blir tvätten vid centrifugering.

OBS! Välj lågt centrifugeringsvarvtal när du tvättar ömtåliga textilier. Vilket tvättprogram som ska väljas för huvudtvätt varierar beroende på vilka kläder som ska tvättas enligt följande anvisningar.

Använda

- **Baby kläder / Baby Care**

I detta tvättprogram sköljs kläderna en extra gång.

- **Sportkläder / Sports**

Detta tvättprogram är lämpligt för fritidskläder.

- **Syntet / Synthetic**

Detta tvättprogram är lämpligt för ganska ömtåliga textilier. Tvättprogrammet är kortare än bomullsprogrammen och tvättintensiteten är låg. Rekommenderat för tvätt av syntetiska plagg (som till exempel skjortor och jackor). Minska mängden tvättmedel vid tvätt av stickade textilier (annars finns det risk för lödder)

- **Mixade material / Mixed**

Välj detta tvättprogram för tvätt som behöver tvättas länge och med hög effekt (till exempel lakan, örngott, badrockar och underkläder).

- **Fintvätt / Delicate**

Detta tvättprogram är lämpligt för ömtåliga textilier. Tvättintensiteten och centrifugeringsvarvtalet är lägre än i tvättprogrammet Syntet / Synthetic. Vi rekommenderar detta tvättprogram för plagg som ska tvättas försiktigt.

- **Ylle / Wool**

Detta tvättprogram är lämpligt för yllekläder för vilka maskintvätt rekommenderas. Ställ in tvätttemperaturen (se tvättråden på klädesplaggen). Välj tvättmedel som är lämpligt för ylle.

- **Tömmning / Drain Only**

Separat tvättprogram för tömning.

- **Centrifugering / Spin Only**

Separat centrifugeringsprogram. Allt vatten ska tömmas ur maskinen innan centrifugering.

- **Sköljprogram / Rinse&Spin**

Separat tvättprogram för sköljning och centrifugering.

- **Eco tvätt / Eco Wash**

Energisnålt tvättprogram för lätt smutsiga kläder (temperaturen är begränsad till 40 °C).

- **Snabbtvätt 15' / Quick 15'**

Detta tvättprogram är lämpligt för snabb tvätt av ett fåtal normalsmutsiga klädesplagg.

- **Bomull / Cotton**

Detta tvättprogram är lämpligt för kläder som används dagligen. Tvättiden är lite längre och effektiv. Rekommenderas för tvätt av bomullstextilier som används dagligen (till exempel underlakan, påslakan, örngott, morgonrockar och underkläder).

- **Bomull intensiv / Cotton Intensiv**

Tvättresultatet kan förbättras genom att öka tvättiden.

Underhåll

Utför följande innan du påbörjar underhåll: Dra ut stickkontakten (eller bryt nätspänningen) och stäng vattenkranen.

- Det är förbjudet att använda lösningsmedel i tvättmaskinen (tvättmaskinen kan skadas, giftiga gaser kan genereras eller explodera).
- Spola inte vatten direkt på tvättmaskinen.
- Det är förbjudet att använda rengöringsmedel som innehåller kloroxylenol för att rengöra tvättmaskinen.

Rengöring och underhåll av tvättmaskinens hölje.

Med korrekt underhåll förlängs tvättmaskinens livslängd. Tvättmaskinens ytor kan vid behov rengöras med utspätt, neutralt rengöringsmedel (utan slipmedel). Torka omedelbart bort eventuellt utspillt vatten. Höljet kan skadas av vassa föremål.

Rengöra trumma


Avlägsna omedelbart rost inuti trumman som kan uppstå av ej borttagna metallföremål från tvätten med klorfritt lösningsmedel. Använd inte stålull.

Frysskydd

Om tvättmaskinen är installerad i ett rum där det kan bli minusgrader måste du tappa ur allt vatten i tömningsröret och inloppsröret efter användning.

Avlägsna kvarvarande vatten i inloppsröret:


1. Se till att enheten pumpat ur allt vatten
2. Stäng vattenkranen.
3. Skruva av inloppsslangen från vattenkranen samt dräneringslangen och stoppa dess ändrar i en behållare, detta för att eventuellt vatten i slangarna skall dräneras.
4. Tappa även ur resterande vatten som finns kvar i utrymmet för tömningspumpen. Samla upp vattnet i ett lågt uppsamlingskärl. Gör enligt nedan bilder.



Underhåll

Rengöra tvättmedelsfack och spår

1. Tryck ned spärren på mjukmedelsfacket inuti tvättmedelsluckan.
2. Lyft upp spärren och ta ut mjukmedelsfacket. Tvätta alla fack med mjuk borste och vatten.
3. Sätt tillbaka mjukmedelsfacket och skjut in luckan på plats.





Rengöra inloppsfilter

Om det inte kommer något eller endast lite vatten när du öppnar vattenkranen måste inloppsfiltret rengöras.




Rengöra inloppsslangens filter:

1. Stäng vattenkranen.
2. Skruva av inloppsslangen från vattenkranen.
3. Tvätta filtret i vatten.
4. Anslut inloppsslangen igen.



Tvätta filtret i tvättmaskinen:

1. Skruva av inloppsslangen från tvättmaskinens baksida.
2. Dra ut filtret med en spetstång, tvätta det och sätt tillbaka det.
3. Anslut inloppsslangen igen.
4. Öppna vattenkranen och försäkra dig om att det inte läcker vatten.




Underhåll

Tömningspumpen

Tömningspumpens filter filtrerar trådar och små främmande föremål från tvätten. Rengör filtret regelbundet för att säkerställa att tvättmaskinen fungerar korrekt.

Inspektera filtret regelbundet (oftare om du tvättar mycket smutsig tvätt eller om du tvättar ofta). Inspektera pumpen om tvättmaskinen inte töms och/eller kör centrifugering. Tvättmaskinen kan låta ovanligt mycket vid tömning på grund av att föremål blockerar pumpen.

Utför följande på servicepanelen:



Öppna servicepanelen

Skruva loss
pumplocket

Avlägsna pumplocket
och ta bort ev smuts

Sätt tillbaka pump-
locket och stäng
servicepanelen.

Varning!

När tvättmaskinen används (beroende på vilket tvättprogram som körs) kan det finnas varmt vatten i pumpen. Avlägsna inte pumplocket under pågående tvättprogram (vänta tills tvättmaskinen har avslutat tvättprogrammet och allt vatten är tömt). Försäkra dig om att du skruvar åt locket ordentligt när du sätter tillbaka det.

Felsökning

Problem	Orsak	Åtgärd
Tvättmaskin startar inte		Kontrollera att luckan är ordentligt stängd. Kontrollera att stickkontakten är korrekt isatt. Kontrollera att vattenkranen är öppnad. Kontrollera om START/PAUS-knappen är nedtryckt. Kontrollera om AV/PÅ-knappen är nedtryckt.
Luckan går inte att öppna	Tvättmaskinens säkerhetsfunktion fungerar inte	Koppla bort maskinen från nätspänning.
Vattenläckage	Vatten droppar från inloppslang och/eller dräneringslang.	Kontrollera och dra åt inloppslangen eller dräneringsslangen. Rengör slangen och se till att dräneringslangen inte är veckad.
Vatten flödar upp under maskinen.	Inloppsröret är inte korrekt anslutet. Dräneringsslangen läcker vatten.	Sätt fast inloppsröret. Byt dräneringsslangen.
Indikator eller display lyser inte.	Strömförsörjningen är bruten. Problem med kretskort. Anslutningsproblem för kablage.	Kontrollera om strömförsörjningen är bruten och om stickkontakten är korrekt ansluten. Kontakta servicetekniker om så inte är fallet.
Dåligt tvättresultat	Kläderna är för smutsiga. Inte tillräckligt mycket tvättmedel.	Välj lämpligt tvättprogram. Fyll på korrekt mängd tvättmedel (se anvisningar i tvättmedelsförpackningen).
Onormal ljudnivå och stora vibrationer		Kontrollera om fästskruvarna har lossnat. Kontrollera om tvättmaskinen är installerad på stabilt och plant golv. Kontrollera om det finns några hårspänner eller andra metallföremål i maskinen. Kontrollera om tvättmaskinens ben är korrekt justerade.

Felsökning

LED-display	Beskrivning	Orsak	Åtgärd
E30	Problem med låsning av lucka	Luckan är inte ordentligt stängd.	Starta om när luckan är stängd.
		Kontakta servicetekniker om problem kvarstår.	
E10	Problem med vattenfyllning under tvättning.	Vattenkranen är inte öppnad eller så är vattentrycket lågt. Inloppsventilens filter är igensatt. Inloppsröret är vridet.	Öppna vattenkranen eller vänta tills vattentillförseln är normal. Kontrollera inloppsventilens filter. Räta ut vattenledningen och kontrollera de andra vattenkranarna i rummet.
		Kontakta servicetekniker om problem kvarstår.	
E21	Problem med tömning under tvättning	Dräneringsslangen är igensatt eller vriden eller så är tömningspumpen igensatt	Tvätta och räta ut dräneringsslangen. Tvätta tömningssumpens filter.
		Kontakta servicetekniker om problem kvarstår.	

Produktspecifikationer

Tvättmängd	7,0 kg
Mått (B x D x H)	595 x 495 x 850
Vikt	61 kg
Märkeffekt	2050 W
Strömförsörjning	220–240 V~50 Hz
Märkström	10 A
Standard vattentryck	0,05 MPa~1 MPa

Tekniska data

Märke: Elvita

Modell: CTM2714V

Tvättmängd: 7 kg

Energieffektivitetsklass: A+++

EU Ecolabel: –

Energiförbrukning: 175 kWh/år (baserat på 220 standardtvättcykler för bomull på 60 °C/40 °C med full och halv last samt förbrukning för lågeffektlägen).

Faktisk energiförbrukning varierar beroende på hur tvättmaskinen används.

Vattenförbrukning: 10 000 l/år (baserat på 220 standardtvättcykler för bomull på 60 °C/40 °C med full och halv last). Faktisk vattenförbrukning varierar beroende på hur tvättmaskinen används.

Centrifugeringsklass B (på en skala från G (lägst effektivitet) till A (högst effektivitet))

Max. centrifugeringsvarvtal: 1400 varv/min

Förbrukningsvärden (1400 varv/min):

Standardprogram	Tvättkapacitet	Energiförbrukning	Vattenförbrukning	Återstående fuktinnehåll	Programtid
Cotton 60 °C (bomull)	7 kg	0,92 kwh	50 L	48 %	219 min
Cotton 60 °C (bomull)	3,5 kg	0,68 kwh	42 L	53 %	205 min
Cotton 40 °C (bomull)	3,5 kg	0,64 kwh	42 L	53 %	199 min

Anmärkingar:

1. Programinställning för test enligt tillämplig standard EN-60456-2011.
2. Vid användning av testprogram tvättar du specificerad last med max. centrifugeringsvarvtal.
3. Faktiska parametrar varierar beroende på hur tvättmaskinen används och kan avvika från parametrar i ovan nämnda tabell.

Strömförbrukning avstängd: 0,5 W

Strömförbrukning standby-läge: 1 W

Luftburet akustiskt buller (tvättning): 58

Luftburet akustiskt buller (centrifugering): 78

Anmärkingar: Luftburet akustiskt buller under tvättning/centrifugering för standardprogram (60 °C) för bomull vid full last.

Contents

Safety instructions	47
Remember	50
<i>Moving the washing machine</i>	50
<i>Disposing of your appliance</i>	50
Overview	51
Installation	52
<i>Unpacking the washing machine</i>	52
<i>Disposing of packaging</i>	52
<i>Removing transit bolts</i>	52
<i>Choose the location</i>	52
<i>Levelling</i>	52
<i>Electrical supply</i>	52
<i>Water supply</i>	53
<i>Drain hose</i>	53
Using the appliance	54
<i>Checklist and preparations before washing clothes</i>	54
<i>Garments that are unsuitable for machine washing</i>	54
<i>Empty all pockets</i>	55
<i>Divide clothing into the following groups</i>	55
<i>Use a suitable detergent</i>	55
<i>Load size</i>	56
<i>Control panel</i>	57
<i>Table of wash programmes</i>	59
<i>Using the washing machine for the first time</i>	60
<i>Adding detergent to the washing machine</i>	60
<i>Starting the washing machine</i>	60
<i>Choosing the wash programme</i>	60
Maintenance	62
<i>Cleaning and maintaining the exterior of the machine</i>	62
<i>Cleaning the drum</i>	62
<i>Protecting from frost</i>	62
<i>Cleaning the detergent drawer and guides</i>	63
<i>Cleaning the supply filters</i>	63
<i>Cleaning the supply hose filter</i>	63
<i>Cleaning the filter inside the machine</i>	63
<i>Drain pump</i>	64
Troubleshooting	65
Product specifications	67
Technical data	67

Safety instructions

- If the power cord is damaged it must be replaced by the manufacturer, the manufacturer's representative or an authorised person (a damaged power cord can be very dangerous).
- Use the hose kit that is supplied with the appliance (do not reuse an old hose kit).
- The washing machine is intended for indoor use.
- This appliance can be used by children from the age of 8 and by individuals with reduced physical, sensory or mental capacities, or who lack experience, provided they are supervised by a responsible person or instructed in the safe use of the appliance and understand the risks involved in its use. Do not let children play with the appliance. Children may only carry out cleaning and maintenance if they are supervised by an adult.
- Unplug the appliance from the wall socket before you start cleaning or maintenance.
- Make sure that all pockets are emptied (hard or sharp items such as coins, jewellery, nails, screws or stones could seriously damage the appliance).
- Check that there is no water left in the drum before you open the door. Do not open the door if you see water inside the drum.
- Check that pets or children have not climbed into the washing machine. Always check the washing machine before you use it.
- The glass door can get very hot during washing. Make sure that children and pets cannot get near the washing machine when a wash programme is running.
- Check that the mains voltage and frequency match the specifications on the washing machine's rating plate.

Safety instructions

- Do not use fuses with a lower current rating than shown on the washing machine's rating plate. Do not unplug the machine when your hands are wet.
- Only plug the power cord into an earthed wall socket (otherwise there is a risk to your safety and that of others). Make sure that the wall socket is correctly and reliably earthed.
- Packaging materials can be dangerous to children. Make sure that children cannot play with any packaging material (such as plastic bags, foam, etc.).
- Take care to avoid scalding yourself when hot water is pumped out of the washing machine
- Do not install the appliance in a damp or wet area where it could be exposed to water spray.
- Make sure that connections to water and electrical systems are made by authorised technicians according to the manufacturer's instructions and local safety precautions.
- Remove all packaging and transit bolts before using the washing machine. If this is not done the washing machine could be seriously damaged during use.
- Run a complete wash programme with the washing machine empty before you do the first wash.
- This washing machine is only intended for domestic use and for fabrics that are intended for machine washing.
- Do not attempt to wash rugs in the machine.
- Do not add water manually during washing.

Safety instructions

- Wait 2 minutes after the wash programme is finished before opening the door.
- Do not climb on to the machine or sit on it.
- Do not lean against the door.
- Close the door with just enough force (do not slam it). If it is difficult to close the door it may be obstructed by clothing.
- This washing machine is not intended to be built in.

Remember

Moving the washing machine



- If you need to move the appliance, the transit bolts must first be refitted by a qualified technician.
- Empty all the water out of the machine before moving it.
- Handle the washing machine with care. Do not hold on to the projecting parts of the washing machine when you lift it.

Disposing of your appliance


All electrical and electronic appliances must be disposed of by law at a recycling station (and some parts must be recycled). Electrical and electronic appliances that are marked with the recycling symbol must be taken to a recycling station for disposal.



Overview



Enclosed accessories



Installation

Unpacking the washing machine

Unpack the washing machine and make sure that it has not been damaged during transport. Also make sure that all the components shown in the “Overview” section are present. Contact the retailer immediately if the washing machine has been damaged during transport or if any components are missing.


Disposing of packaging

The packaging materials used on this washing machine can be harmful to children. Dispose of packaging correctly and make sure that children cannot play with it. Dispose of packaging according to local regulations. Do not dispose of packaging material with regular household waste.

Removing transit bolts

Remove the transit bolts from the rear of the washing machine before you use it.

1. Undo all the transit bolts with a ring spanner and remove them (saving them for future use).
2. Cover the holes that remain with the caps provided.




Choose the location

Before installing the washing machine, you need to choose a location that meets the following requirements:

- A stable, dry and flat surface (see diagram on Adjusting the legs if the floor is not flat).
- Make sure there is adequate ventilation.
- The room temperature must exceed 0°C.

Levelling

1. Undo the nuts on the feet by hand.
2. Adjust the feet until the appliance is level and steady.
3. Tighten all the lock nuts.



Electrical supply

- Make sure that the available electrical system capable of powering the appliance (current, voltage and wiring), see the rating plate.
- Plug in the appliance to a correctly installed and earthed wall socket.
- Do not use a plug or extension cord that are intended for other types of international plugs.
- Do not touch the plug if you have wet hands.
- Grasp the plug firmly when you plug it in or unplug it. Never pull on the power cord.
- If the power cord is damaged or shows signs of being defective, it must be replaced immediately (contact the manufacturer or service centre).



Installation

Water supply

We recommend that you use an authorised installer to connect to the water supply.

Connect the supply hose as shown in the diagram.

1. Connect the elbow to the water tap and turn clockwise to tighten.
2. Connect the other end of the supply hose to the inlet valve at the rear of the washing machine and tighten it securely (clockwise).




Note! If there is any leakage from the hose after connection, repeat all the steps for connecting the supply hose. Use a conventionally designed tap to supply the water. If the tap has a square spout or is too large in diameter you should replace it with a standard tap.

Drain hose

There are two ways to connect the drain hose:


Alternative 1: Connect it to a waste pipe. This method is suitable if there is a suitable coupling accessible.



The drain hose should run no higher than 100 cm above the floor.

Alternative 2: Connect to a sink or open drain.

- Secure the drain hose once it has been installed.
- Position the drain hose so that water cannot leak on to the floor.



Using the appliance

Checklist and preparations before washing clothes

Read this section carefully to avoid problems with the washing machine or damage to clothes.


- When you wash clothes for the first time the colours may run. Dip a white towel in detergent and rub it lightly on the inside of a garment or some other hidden part of the garment to test whether the colour transfers to the towel.
- Wash clothes that discolour easily (such as shawls) separately for the first few washes.
- Pre-wash stains on cuffs, collars or pockets carefully using a brush and liquid detergent. Then wash them in the washing machine.
- Check the care labels on garments before you wash them (follow instructions regarding temperature and washing method). Garments that are washed at the wrong temperature or using the wrong method may discolour or be damaged.

Remember!

Do not leave wet clothes lying in the washing machine for a long time waiting to be washed.

Garments that are unsuitable for machine washing


- Some garments may lose their shape if they are soaked in water: ties, waistcoats, some outerwear etc. can shrink considerably if they are soaked in water.
- Items such as ruched, starched or embroidered garments can lose their shape when they are soaked in water.
- Some garments made from cotton or wool can easily lose their shape.
- Decorative clothing and folk dress are examples of items that easily become discoloured.
- Do not machine wash garments that do not have a material label or care label.
- Do not machine wash garments that are stained with solvents such as petrol, naphtha, benzene, thinners or alcohol.



Using the appliance


Empty all pockets

Hard items such as jewellery or coins may damage the washing machine.



Divide clothing into the following groups

- Read the care label and divide garments as follows: cotton, mixed fibre, silk, synthetics, wool and manmade fibres.
- Separate coloured and white garments. You should always wash new coloured garments separately for the first wash to avoid discolouring other items.
- You get better washing results when you mix garments of different sizes.
- Wash delicate garments separately. Choose a delicates programme when you wash pure wool items, curtains or silk. Read the care label on all garments.
- Sort clothing before placing it in the washing machine. Remove any hooks from curtains.
- Decorative items on clothing can damage the washing machine. Turn garments that have buttons or embroidery inside out before placing them in the washing machine.
- Fasten all zips and buttons. Tie the ends of any loose cords together.
- Garments with metal fittings, such as bras, belts and metal buttons may damage the washing machine. Place garments like this in a washing bag designed for this purpose.



Use a suitable detergent

- Use a machine washing detergent that is suitable for the fabrics you intend to wash (cotton, synthetics, delicates and wool).
- Adjust the amount of detergent to suit the colour, wash temperature, degree and type of soiling.
- If you use too much detergent or if the wash temperature is too low, the detergent may not dissolve. This can leave residue on clothing, pipes and the washing machine that may affect future washes.
- Bleaches are alkaline and may damage clothing, so use them sparingly.

Important!

Keep detergents and other additives in a safe, dry place where children cannot reach them.

Using the appliance

Load size

If you put too much clothing in the washing machine it may give poorer results. See the table below for recommended wash loads.


Fibre type	Wash capacity: 7 kg
Cotton	7.0 kg
Synthetics	3.5 kg
Wool	2.0 kg
Delicates	2.5 kg

Remember!

Garments that produce a lot of lint should be washed separately (otherwise the lint can transfer to other garments). Black garments and cotton clothing easily attract lint, so they should also be washed separately.

Using the appliance

Control panel



1. Programme selector

- Choose your desired wash programme. See the section on “Choosing the wash programme” later in the user manual.

2 LED display

3 ON/OFF button

- Used to turn the washing machine on or off.

4 Delay

This button lets you set a delayed start (0–24 hours). You can use this feature as follows:

- Choose the wash programme.
- Press Delay to set a delayed start time.
- Press START/PAUSE to activate delayed start.

You can cancel this feature as follows: Press Delay until the display shows 0H. This feature can only be switched off once the wash programme has started. If you have already started the wash programme you can interrupt it by pressing the ON/OFF button.

Notes: If the power is cut while the machine is running a wash programme, the current wash programme will be stored in memory. When the power is restored, press START/PAUSE (the wash programme will resume at the point it was interrupted).

5 Speed

- Select the spin speed, max, 1400 rpm.

6 Temp

- Set the wash temperature, max. 90°C.

7 START/PAUSE

- This is used to start or pause the wash programme.

Using the appliance

- **Child Lock** 

You can use this feature to lock the washing machine so that children cannot start it. Press "Delay" and "Speed" simultaneously while a wash programme is running (the icon will light up, and "START/PAUSE" and the programme selector will both be locked). The only button that is not locked is "ON/OFF".

Press the same two buttons simultaneously again to unlock the child lock (the icon light will go out).

If the power to the washing machine is cut, the child lock will also be deactivated. NOTE! The child lock remains active when the wash programme has finished.

- **Turning off the buzzer** 


The washing machine has a buzzer warning feature that can be turned off. Press and hold the "Temp" button for 3 seconds to turn the buzzer off (a beep indicates that the buzzer is deactivated). To turn the buzzer back on, press the same button again for 3 seconds.

- **Reducing foam**

If too much detergent is used it increases the degree of foaming, which has a negative effect on washing results. The washing machine automatically monitors the amount of foam and can trigger a feature that reduces the degree of foaming.

Using the appliance

Table of wash programmes

Wash programme Description	Wash load (kg)	Detergent drawer			Default temp. °C	Default time hours	Default spin speed rpm
		Tray I*	Tray II				
Cotton intensive	7.0	X	●	○	40	1:58	1000
Cotton 60°C	7.0	X	●	○	60	3:39	1400
Cotton 40°C	7.0	X	●	○	40	3:35	1400
Cotton 20°C	7.0	X	●	○	20	1:13	1000
Quick 15'	2.0	X	●	○	COOL	0:15	800
Eco Wash	2.0	X	●	○	30	1:06	800
Rinse & Spin	7.0	X	X	○	-	0:31	1000
Baby Care	7.0	X	●	○	60	1:39	1000
Sports	3.5	X	●	○	40	1:19	800
Synthetic	3.5	X	●	○	40	1:33	1200
Mixed	7.0	X	●	○	40	1:13	1000
Delicate	2.5	X	●	○	30	1:00	600
Wool	2.0	X	●	○	40	1:06	400
Drain Only	-	X	●	X	-	0:01	0
Spin Only	7.0	X	●	X	-	0:12	1000

*Pre-wash programme is not available on this model

Energy rating: A+++

Energy test programme: Cotton 60°C/40°C (cotton), spin: max. speed (all other settings are defaults).

Half load for machine (7.0) kg: 3.5 kg.

Cotton 60°C/40°C is the standard programme for cotton (60°C/40°C) (see care label). These wash programmes are suitable for washing normally soiled cotton laundry. They are also the most energy-efficient and water-efficient way to wash this type of cotton laundry.

● Required

○ Optional

X Not available

Notes: The parameters given in this table are only provided for reference. Actual parameters may differ slightly from those shown in the above table.

Using the appliance

Using the washing machine for the first time

Run a complete wash cycle with an empty washing machine before you do the first wash.


1. Pour the detergent into the detergent drawer and close it.
2. Press the ON/OFF button.
3. Press the START/PAUSE button.

The detergent drawer is divided into the following trays:

I: NOT used on this model.

II: Main wash

☼ Additives such as softener or starch.



Adding detergent to the washing machine

1. Open the detergent drawer.
2. Pour detergent into tray II.
3. Pour softener into tray ☼ (if desired).

Notes:

- We recommend that you dilute thick or viscous detergents or additives with a little water before pouring them into the detergent tray, to prevent the tray from becoming blocked and overflowing when the water is added.
- Choose a detergent that is suitable for the wash temperatures you intend to use (to give the best results and lowest energy consumption).

Starting the washing machine

- Put the clothing in the drum and add detergent and softener.
- Press the ON/OFF button.
- Select the wash programme and any options.
- Press the START/PAUSE button.

Choosing the wash programme

Choose a wash program to suit the type of clothing, wash load and the degree of soiling (see table of wash temperatures).

1. Select the wash programme using the programme selector.
2. Set the temperature. As a rule of thumb the energy consumption increases with temperature.
3. Set the spin speed. The higher the spin speed, the drier the clothing will be after spinning.

NOTE! Choose a low spin speed if you are washing delicates. The wash programme you should choose for the main wash depends on the type of clothing you intend to wash, as explained below.

Using the appliance

- **Baby Care**

This wash programme gives the clothing a second rinse.

- **Sports**

This wash programme is suitable for sportswear.

- **Synthetic**

This wash programme is suitable for relatively delicate fabrics. This is shorter than the cotton programmes and is gentle on fabrics. It is recommended for washing synthetic garments (such as shirts and jackets). Reduce the amount of detergent when washing knitted fabrics (otherwise it can cause excessive foaming).

- **Mixed**

Choose this programme for garments that require longer and more intensive washing.

- **Delicate**

This wash programme is suitable for delicate fabrics. It provides a gentler wash and lower spin speed than the Synthetic programme. We recommend this wash programme for garments that need to be washed gently.

- **Wool**

This wash programme is suitable for woollens that can be machine washed. Set the wash temperature according to the care labels on the garments. Choose a detergent that is suitable for wool.

- **Drain Only**

Separate programme for draining the machine.

- **Spin Only**

Separate programme for spin drying. The water must be drained from the machine before spinning.

- **Rinse & Spin**

Separate programme for rinsing and spin drying.

- **Eco Wash**

Energy-saving programme for lightly soiled clothing (temperature is limited to 40°C).

- **Quick 15'**

This wash programme is suitable for washing a few normally soiled garments.

- **Cotton**

This wash programme is suitable for clothing that is used daily. The wash cycle is a little longer and more intense. It is recommended for cotton fabrics that are used daily, such as sheets, duvet covers, pillow cases, dressing gowns and underwear.

- **Cotton Intensive**

Washing results can be improved by increasing the wash time.

Maintenance

Do the following before you carry out maintenance: Unplug the washing machine (or turn off the mains supply) and turn off the water tap.

- Never use any solvents inside the washing machine (they may damage the machine, produce toxic gases or cause an explosion).
- Do not spray the washing machine directly with water.
- Never use cleaning products that contain chloroxylenol to clean the washing machine.

Cleaning and maintaining the exterior of the machine.

Correct maintenance can extend the working life of the washing machine. If required, the exterior of the washing machine can be cleaned with a dilute neutral detergent (that does not contain abrasives). Wipe up any water spills immediately. The exterior of the machine may be damaged by sharp objects.


Cleaning the drum

Any rust that forms inside the drum due to contact with metal objects that have been left in laundry should be removed immediately with chlorine-free detergent. Do not use steel wool.

Protecting from frost

If the washing machine is installed in a room where the temperature could drop below zero you should drain all the water from the drain hose and supply hose after use. Removing remaining water from the supply hose:


1. Make sure all the water has been pumped out of the appliance.
2. Turn off the water tap.
3. Unscrew the supply hose from the water tap, disconnect the drain hose and place both hose ends in a container so that any water in the hoses can drain out.
4. Also drain out any water remaining in the drainage pump compartment. Collect the water in a shallow container. This process is illustrated in the diagrams below.



Maintenance

Cleaning the detergent drawer and guides

1. Press down the clip in the softener tray inside the detergent tray.
2. Lift up the clip to remove the softener tray. Wash all the trays with a soft brush and water.
3. Refit the softener tray and slide the detergent drawer back into place.





Cleaning the supply filters

If there is little or no flow of water when you open the tap you will need to clean the supply hose filter.




Cleaning the supply hose filter:

1. Turn off the water tap.
2. Unscrew the supply hose from the water tap.
3. Wash the filter in water.
4. Reconnect the supply hose.



Cleaning the filter inside the machine:

1. Unscrew the supply hose from the rear of the machine.
2. Pull out the filter using needle-nosed pliers, wash it and refit it.
3. Reconnect the supply hose.
4. Turn on the water tap and make sure there are no water leaks.




Maintenance

Drain pump

The drain pump filter captures threads and small foreign objects from the water. Clean the filter regularly to ensure correct operation of the washing machine.

Inspect the filter regularly (and more often if you wash heavily soiled laundry or wash frequently). Inspect the pump if the washing machine does not empty or keeps on spinning. The washing machine may make an unusual noise during emptying if an object is blocking the pump.

Follow the steps below at the service panel:



Open the service panel

Unscrew the pump cover

Remove the pump cover

Close the service panel

Warning!

The water in the pump may get hot when the washing machine is in use (depending on which wash programme is selected). Do not remove the pump cover during a wash programme (wait until the wash programme has ended and the water has been drained). Make sure you tighten the cover securely when you refit it.

Troubleshooting

Problem	Cause	Action
Washing machine does not start.		Check that the door is properly closed. Check that the machine is plugged in correctly. Check that the water tap is turned on. Check that the START/PAUSE button is pressed in. Check that the ON/OFF button is pressed in.
Door does not open.	Fault in door safety interlock.	Unplug the machine.
Water leak.	Water dripping from the supply hose and/or drain hose.	Check and tighten the supply hose or drain hose connections. Clean the hose and make sure the drain hose is not kinked.
Water flows out from beneath the machine.	Supply hose is not securely connected. Drain hose is leaking water.	Connect the supply hose correctly. Replace the drain hose.
Status light or display does not light up.	No power. Fault in circuit board. Fault in harness connection.	Check that there is power at the socket and the plug is properly plugged in. If this is not the problem, contact a service technician.
Poor washing results.	Laundry is too dirty. Insufficient detergent.	Choose a suitable wash programme. Fill with the correct amount of detergent (see advice on detergent packaging).
Abnormal noise and excessive vibration.		Check if fixing screws have come loose. Check that washing machine is installed on a flat, stable floor. Check whether there are any hair clips or other metal items inside the machine. Check that the washing machine's feet are correctly adjusted.

Troubleshooting

LED display	Description	Cause	Action
E30	Problem locking door.	Door is not closed properly.	Restart when the door is closed.
		Contact a service technician if the problem persists.	
E10	Problem filling with water during washing.	Water tap is not turned on or the water pressure is low. Inlet valve filter is blocked. Supply hose is kinked.	Turn on the water tap or wait until water pressure returns to normal. Check the inlet valve filter. Straighten the supply hose and check the other water taps in the room.
		Contact a service technician if the problem persists.	
E21	Problem emptying water during washing.	The drain hose is blocked or kinked, or the drain pump is blocked.	Wash and straighten out the drain hose. Wash the drain pump filter.
		Contact a service technician if the problem persists.	

Product specifications

Wash load	7.0 kg
Dimensions (W x D x H)	595 x 495 x 850
Weight	61 kg
Rated power	2050 W
Power supply	220–240 V ~50 Hz
Rated current	10 A
Standard water pressure	0.05 MPa~1 MPa

Technical data

Brand: Elvita

Model: CTM2714V

Wash load: 7 kg

Energy efficiency class: A+++

EU Ecolabel: –

Energy consumption: 175 kWh per year (based on 220 standard wash cycles for cotton at 60°C/40°C at full and partial load, and consumption in low-power modes).

Actual energy consumption will depend on how the washing machine is used.

Water consumption: 10,000 litres per year (based on 220 standard wash cycles for cotton at 60°C/40°C at full and partial load). Actual water consumption will depend on how the washing machine is used.

Spin-drying efficiency class B on a scale from G (least efficient) to A (most efficient).

Max. spin speed: 1400 rpm

Consumption values (1400 rpm):

Standard programme	Wash load	Energy consumption	Water consumption	Remaining water content	Programme duration
Cotton 60°C	7 kg	0.92 kWh	50 litres	48%	219 min
Cotton 60°C	3.5 kg	0.68 kWh	42 litres	53%	205 min
Cotton 40°C	3.5 kg	0.64 kWh	42 litres	53%	199 min

Notes:

1. Programme setting for testing in accordance with applicable standard EN60456-2011.
2. When using the test programmes, wash at the specified load using the maximum spin speed.
3. Actual parameters will depend on how the washing machine is used and may differ from the figures given in the table above.

Power consumption with power off: 0.5 W

Power consumption on standby: 1 W

Airborne acoustic noise (washing): 58

Airborne acoustic noise (spinning): 78

Notes: Airborne acoustic noise emissions during washing/spinning for the standard 60°C cotton programme at full load.



GARANTI WARRANTY

Kvalitetsgaranti gäller för konsument

Quality warranty applies to consumer


ELVITA

Marknadsförs av EEL AB. +46 (0) 501-39 90 00.